

User Manual Malko Drink Dispenser

Use

With our Drink dispenser you conveniently serve cold beverages. Fill the chiller element with tap water and place in the freezer before use.

You open the tap by gently pushing the handle down. It will shut once you let go of the handle. The drip tray will keep your hydration station fresh throughout the service.


Care instructions

The container should be hand washed after use with warm water and regular washing-up liquid. Let the chiller element defrost before washing and drying.


If the dispenser doesn't work

If the drink dispenser doesn't work, or leak, it can be due to one of the following reasons:


- The tap is too loosely tightened. Tightened as described below.
- The tap is not straight. Remove the tap and reassemble, follow the instructions described below.
- The washers might be old and/or dry, which could lead to leakage. Replace the washers, or the entire tap.
- Pulp or residue from fruits might be stuck in the tap. Remove the handle of the tap and rinse thoroughly.



- Put one of the washers on the tap and push the tap through the hole from the outside.
- Turn the tap 90 degrees clockwise, according to the illustration.



- Place the other washer on the tap from the inside.
- Screw on the nut from the inside. Make sure that the nut is straight and pull tightly, do not use any tool for this action.



- Pull the tap back clockwise 270 degrees as you hold the nut in place. This pulls the tap in place just firmly enough to keep it tight.
- Turn the tap handle into position.