

CARE INSTRUCTIONS

August Lundh AB

DO'S





- PC Safe & BPA Free drink- and tableware is microwave safe for reheating, but not for cooking food.
- Important – please wash thoroughly before use to ensure full effectiveness of this product.
- Unbreakable products should be treated like any fine glassware.
- Unbreakable products are commercial dishwasher safe.
- Wash our unbreakables as soon as possible to maintain clarity and quality.
- To avoid scratching, use only non-abrasive sponges and pads to clean our drink & tableware products.

DON'TS

- Never place the tableware near or on direct heat. For instance, to not put inside or on electric or gas cookers.
- Do not use bleach or abrasives of any kind i.e. scouring pads, scourers, cleaning powders or liquids etc.
- Avoid contact with steam on a regular basis. Steam might weaken polycarbonate and might cause it to crack.
- To prevent scratching and damage, do not overload your dishwasher rack.

DECLARATION OF COMPLIANCE

Our unbreakable range meets the requirements of the current EU food contact. For the entire declaration of compliance, please contact us.

Information on materials				
	PC Safe	✓ -20/+100	✓	✓
	BPA Free	✓ -20/+85	✓low	✓
	PP	✗ -40/+85	✓low	✓
	PUR	✗ -30/+100	✗	✗
	TPE	✓ -50/+125	✗	✓
	PA	✓ -30/+140	✓	✓
	HDPE	✓ -40/+90	✗	✓

August Lundh - We provide designed plastics catering equipment for the professional kitchen. Visit our website for more information!

August Lundh AB | Hejargatan 14, SE-632 29 Eskilstuna, Sweden
+46 (0)16 51 72 40 | info@augustlundh.se | www.augustlundh.se

Member of EPIQ - www.epiq.pro



CARE INSTRUCTIONS

August Lundh AB

WASHING

- PC Safe & BPA Free drink and tableware is dishwasher safe and suited to hand washing and sterilising sinks. Sterilising sinks should not exceed 85°C.
- Maximum dishwasher temperatures should be 60°C - 65°C for the wash and 70°C - 85°C for the rinse. Higher temperatures may cause deterioration of the material.
- Some dishwasher detergents/rinse aids may cause stress cracking to polycarbonate tableware. PH value should be below 10, preferable 7 or 8.
- For information on specific detergents please contact your detergent supplier or manufacturer.
- Washing in hot soapy water should prevent any build up or discolouration.
- Milton sterilising fluid may be used to remove discolouration.
- Do not use bactericidal detergents when washing polycarbonate drink & tableware as this may cause deterioration of the material. Always check suitability of the hand wash detergent with the detergent manufacturer.
- It is essential that your detergent and rinse aids are compatible with polycarbonate and that the correct dosages are used. Using too much or leaving tableware to soak for long periods can shorten the life of the product.

LIMITED WARRANTY

August Lundh AB offers a limited 1-year warranty against defects on all products. For more information, please ask for our complete technical sheets.

August Lundh - We provide designed plastics catering equipment for the professional kitchen. Visit our website for more information!

August Lundh AB | Hejargatan 14, SE-632 29 Eskilstuna, Sweden
+46 (0)16 51 72 40 | info@augustlundh.se | www.augustlundh.se

Member of EPIQ - www.epiq.pro

